


# **Jackery Bolt**

User Guide

#### **Product Overview**

#### Product Layout



- 1. LED light indictor 2. Power button
- 3. Micro USB input port
- 4. LED flashlight
- 5. USB output port 6. Built-in Lightning cable 7. Built-in Micro USB cable

Technical Specification Capacity: 6000mAh Dimensions: 4.3 x 1.9 x 0.9 inch Weight: 6 oz Input: Micro USB 5V / 2A Output:

Lightning cable: 5V / 2.4A max.(single) Micro USB cable: 5V / 2.4A max.(single) USB port: 5V / 2.4A max.(single) or 5V / 2.4A overall Power indication: Four LED indicators

### Instruction


#### Package Content

- Jackery Bolt Battery Pack Micro USB Charging Cable
- User Guide & Warranty

### Charging Jackery Bolt

To charge the Jackery Bolt, use the micro USB charging cable to connect the Bolt to a USB AC adapter or computer USB port. The LED indicator will show on or start blinking.

When all four LEDs are on solid, charging is complete. It takes about 4 hours to fully charge the Bolt.



# Instruction

#### **Charging Your Device**

To charge your device, use the built-in Lightning or Micro USB cable to connect the Bolt to your device, then press the power button once to initiate charging.

You can also get charging from the universal USB port with charging cable of your mobile device.



## Check the Battery Level

Press the power button once to check the battery level by reading the LED indicators.

- 1 LED blinking: level < 5%
- 1 LED on: level in 5%-25%
- 2 LEDs on: level in 26%-50%
- 3 LEDs on: level in 51%-75% 4 LEDs on: level in 76%-100%

# LED Flashlight Function

Press the power button two times to turn on the LED flashlight. Press it again two times to turn off.

# Warnings

When there is one LED light blinking, it's time to recharge the battery. We highly recommend you to recharge the battery at least once a month.

Follow @jackeryinc on Twitter & Facebook www.facebook.com/jackery.inc for the latest Jackery news, tips and updates! You can also visit www.jackery.com for more info.

#### Warning

Read all instructions and warnings prior to using this product. Failure to read and follow these safety instructions could result in fire, explosion, electrical shock or other hazard, causing serious and/or fatal injury and/or property damage.

- 1. Do not modify, disassemble, open, drop, crush, puncture or shred the product.
- 2. Do not expose the product to rain or water. 3. Keep away from open flame or sunlight to
- prevent heat build-up. . Keep away from high voltage devices.
- This product is not a toy, keep away from children.
  Ensure that all persons who use the product read and follow these warnings and instructions.

# Warranty

This product is covered by a limited warranty from Jackery for the original purchaser that covers the product from defects in workmanship and materials for 18 months from the date of purchase (damages through normal wear and tear, alteration, misuse, neglect, accident, service by anyone other than the authorized service center, or act of God are not included).

During the warranty period and upon verification of defects, this product will be replaced when returned with proper proof of purchase.

#### Contacts us

For any inquiries or comments concerning our products, please send an email to hello@jackery.com, and we will respond to you as soon as possible. If there is any quality-related issue with the product, you may request a REPLACEMENT or REFUND by submitting a request form at www.jackery.com/support/